



FLUORIDE EMISSIONS MANAGEMENT GUIDE (FEMG)

Written by

LIGHT METALS RESEARCH CENTRE (LMRC)

Auckland UniServices Limited

The University of Auckland

Under invitation of

Australian Aluminium Council (AAC)

Asia-Pacific Partnership (APP) on Clean Development and Climate

Release date

1st February 2011

Version

Full (Version 4)

This content of this FEMG document is the work of LMRC and the document has been compiled by LMRC for AAC. AAC is entitled to use and reproduce the document and any part of it. Any intellectual property rights in data and scientific information included in the document remain the property of Auckland UniServices Limited and Auckland UniServices Limited retains copyright in all illustrations and compilations included in the document. LMRC may use this data, information and copyright works for other purposes.

AUTHORS

LIGHT METALS RESEARCH CENTRE (LMRC)
Auckland UniServices Ltd
The University of Auckland
Private Bag 92019, Auckland, New Zealand
Email: lightmetals@auckland.ac.nz
Web: www.lightmetals.co.nz

SPONSORS & CONTRIBUTORS

ASIA-PACIFIC PARTNERSHIP FOR CLEAN DEVELOPMENT & CLIMATE (APP)
Web: www.asiapacificpartnership.org

AUSTRALIAN ALUMINIUM COUNCIL (AAC)
PO Box 63, Dickson, Canberra, ACT 2602, Australia
Email: info@aluminium.org.au
Web: www.aluminium.org.au

Table of Contents

1.0	Introduction & Theory	1
1.1	Purpose of the Guide	1
	Why has this guide been written?.....	1
1.2	Scope of the Guide	2
1.3	Structure of the Guide	3
	What kind of information does the guide provide?	3
1.4	Drivers Behind Fluoride Emission Control.....	4
	Why is controlling & reducing fluoride emissions important?.....	4
	What are the legal limits for fluoride emissions?.....	5
	How do fluorides affect people & our environment?	7
	How do fluorides affect the smelter's performance?	8
1.5	Definition of Fluorides	9
	What are fluoride emissions and are there different types?	9
1.6	Mechanisms of Fluoride Generation / Evolution	10
	How do fluorides form in the aluminium smelting process?	10
1.7	Fluoride Escape Pathways	11
	How do fluorides escape the smelter?.....	11
2.0	Overall Fluoride Emission Management System	14
2.1	Introduction.....	14
	What is the overall concept of fluoride emission management system?.....	14
2.2	Control of Work Practices.....	15
	Why it is important to control smelter work practices within their process specifications?.....	15
2.3	Monitoring Systems.....	17
	What are monitoring systems and why are they important?	17
	What are the monitoring systems for fluoride emission?	17
	What are the monitoring systems for plant processes?.....	18
2.4	Response Systems	18
	What are response systems and why are they important?	18
2.5	Smelter Audit Systems.....	19
	What are the smelter audit systems and why are they important?.....	19
2.6	Implementation of the FEMG	20
	How should the FEMG be implemented in a smelter?	20
3.0	Potroom Systems for Reducing Fluoride	22
3.1	Introduction.....	22
3.2	Anode Setting and Dressing.....	25
	What is anode setting?.....	25
	Why is anode setting important?.....	25
	What is anode dressing?.....	25
	How does anode setting impact on fluoride emission?	27
	How does anode dressing impact on fluoride emission?	29
	How to reduce fluoride emission in anode setting and dressing practice?	30
	What are the potential improvements?.....	33
3.3	Metal Tapping	34
	What is metal tapping?	34
	Why is metal tapping important?	34
	How does metal tapping impact on fluoride emission?	35
	How to reduce fluoride emission during metal tapping?	36
	What are the potential improvements?.....	37
3.4	Liquid Bath Transfer	38

	What is liquid bath transfer?	38
	Why is liquid bath transfer important?	38
	How does liquid bath transfer impact on fluoride emission?	39
	How to reduce fluoride emission during liquid bath transfer?	40
	What are the potential improvements?	43
3.5	Carbon Dust Skimming	44
	What is carbon dust skimming?	44
	Why is carbon dust skimming important?	44
	How does carbon dust skimming impact on fluoride emission?	45
	How to reduce fluoride emission during carbon dust skimming?	46
3.6	Routine Measurements	48
	What are the routine measurements?	48
	Why are the routine measurements important?	49
	How does routine measurements impact on fluoride emission?	50
	How to reduce fluoride emission during routine measurements?	51
	What are the potential improvements?	52
3.7	Control Practice	53
	How do anode effects impact on fluoride emission?	53
	How does alumina feeding control impact on fluoride emission?	54
	How does bath height control impact on fluoride emission?	54
	How does voltage control impact on fluoride emission?	55
	How does line amperage increase impact on fluoride emission?	55
	How to reduce fluoride emission through control practice?	56
	What are the potential improvements?	57
3.8	Maintenance Practice	58
	How does hooding system impact on fluoride emission?	58
	How does ducting system impact on fluoride emission?	59
	How does alumina delivery system impact on fluoride emission?	60
	How does superstructure impact on fluoride emission?	62
	How does potroom draft balance impact on fluoride emission?	63
	How does house keeping impact on fluoride emission?	64
	How to reduce fluoride emission through maintenance practice?	64
	What are the potential improvements?	66
4.0	Gas Treatment Centre Systems for Reducing Fluoride	68
4.1	Introduction.....	68
	What is the gas treatment centre?	68
	How does the gas treatment centre remove fluorides?	70
	What are the key parameters to control fluorides in the GTC?	71
4.2	Gas Flow & Pressure Drops over GTC Units	73
	Why is the overall gas flow to the GTC important?	73
	How is gas flow distributed to each GTC unit / compartment?	73
	Why is pressure drop over each GTC compartment important?	74
	What is Air-to-Cloth Ratio and why is this important?	75
	How can we control pressure drops in each GTC compartment?	75
	How do the gas flow & pressure drop in the GTC impact fluoride emission?	76
	How to reduce fluoride emission through control of gas flows & pressure drops in the GTC?	78
	What are the potential improvements?	80
4.3	Alumina Distribution to GTC Units.....	81
	Why is the alumina distribution to the GTC units important?	81
	How is alumina is distributed to each GTC units?	82
	How does the alumina distribution impact fluoride emission?	83
	How to reduce fluoride emission through control of alumina distribution to the GTC units?	84
	What are the potential improvements?	84
4.4	Secondary Alumina Recycle Ratio.....	85
	Why is the secondary alumina recycling ratio important?	85
	How does the secondary alumina recycle ratio impact fluoride emission?	86

	How to reduce fluoride emission through control of secondary alumina recycle ratio?	87
	What are the potential improvements?	87
4.5	Inlet Duct Gas Temperature & Fluoride Level	88
	Why is the temperature of the inlet duct gas important?	88
	Why is the fluoride level of the inlet duct gas important?	88
	How does inlet duct gas temperature impact on fluoride emission?	89
	How does inlet duct gas fluoride level impact on fluoride emission?	90
	How to reduce fluoride emission through control of inlet duct gas temperature & fluoride level	91
	What are the potential improvements?	93
4.6	Bag-House Pulsing / Cleaning	94
	What is the baghouse and why is it important?	94
	What is baghouse pulsing / cleaning?	95
	How does baghouse pulsing / cleaning impact on fluoride emission?	96
	How to reduce fluoride emission through control of baghouse pulsing / cleaning?	97
	What are the potential improvements?	97
4.7	Primary Alumina Supply to GTC	98
	How does primary alumina supply impact on fluoride emission?	98
	How to reduce fluoride emission through control of the primary alumina supply to the GTC?	99
	What are the potential improvements?	99
4.8	Secondary Alumina Silo Level	100
	How does the secondary alumina silo level affect fluoride emissions?	100
	How to reduce fluoride emission through control of the alumina silo level?	101
	What are the potential improvements?	101
4.9	Maintenance Practices	102
	Why are maintenance practises important for the performance of the GTC?	102
	What is hard gray scale (HGS)?	102
	How does hard gray scale impact on fluoride emission?	103
	How does the condition of alumina transport systems impact on fluoride emission?	104
	How does the condition of the main GTC gas fans & gas ducts impact on fluoride emission? ...	105
	How does the baghouse & filter condition impact on fluoride emission?	106
	How to reduce fluoride emission through maintenance practises?	107
	What are the potential improvements?	109
5.0	Smelter Supporting Systems outside the Potroom and Gas Treatment Centre	110
5.1	Introduction	110
	What are the plant areas outside the Potroom and GTC?	110
	Why is good control of all Smelter Supporting Systems important?	111
5.2	Anode Production Circuit	112
	What is the anode production circuit?	112
	Why is anode production circuit important?	113
	How does the anode production circuit impact on fluoride emission?	113
	How to reduce fluoride emission from the anode production circuit?	115
	What are the potential improvements?	115
5.3	Bath Processing Plant	116
	What is the bath processing plant?	116
	Why is bath processing plant important?	116
	How does the bath processing plant impact on fluoride emission?	117
	How to reduce fluoride emission from the control of bath processing?	118
5.4	Raw Materials	119
	What are the raw materials?	119
	How does the raw materials impact on fluoride emission?	120
6.0	Fluoride Emission Measurements	121
6.1	Introduction	121
6.2	Fluoride Emission Measurement for GTC	122
	How to measure fluoride emissions from GTC?	122

6.3	Fluoride Emission Measurement for Potroom.....	132
	How to measure fluoride emissions from potroom?	132
6.4	Fluoride Emission Measurement with Alternative Methods	138
	How to measure fluoride emissions with alternative methods?	138
6.5	Measurement Safety	138
6.6	Continuous Fluoride Emission Monitoring.....	139
	What are continuous fluoride measurements and what value can they offer?	139
7.0	Glossary of Terms	140
8.0	Appendices	144
	Appendix I: Typical Smelter Layout	144
	Appendix II: Smelter Audit Survey Worksheets.....	145
	POTLINE AUDIT SURVEY	145
	GAS TREATMENT CENTRE (GTC) AUDIT SURVEY	152
	Appendix III: Smelter Case Study 2010, at Henan Zhongfu Industrial Co. Ltd	158
	A. Summary	158
	B. Background / Purpose of the FEMG Case Study	158
	C. External Audit Surveys & Identification of Improvements from FEMG.....	159
	D. Implementation & Training Workshops for FEMG Practices	160
	E. Installation of Fluoride Monitoring Equipment	161
	F. Feedback from Smelter on FEMG	162
	G. Challenges for Fluoride Management in Chinese Smelters	162

***Introduction
to the FEMG***

***Scope & Structure
of the FEMG***

***Drivers for Fluoride
Management***

1.0 Introduction & Theory

Generation of unwanted fluoride by-products from the aluminium smelting process is unfortunately unavoidable with today's state of technology. However, the release of fluorides into the surrounding environment can be reduced.

With careful management and control of both operations and maintenance practises around the plant, smelters are able to reduce the amount of fluorides they release into the environment, achieving levels demonstrated by the world's best practise.

1.1 Purpose of the Guide



Why has this guide been written?



The Fluoride Emission Management Guide (FEMG) has been written for all smelters in China, and for managers, engineers and operators alike, to:

- 1) Increase understanding of the factors that control fluoride evolution and emissions, and
- 2) Detail what operating, control and maintenance practises are required in order for smelters to control and reduce their fluoride emissions.

The guide focuses mainly on improvements to work and maintenance practises, as these are typically low cost and allow a smelter to maximise its environmental performance with its existing technology. Less emphasis is placed on technology improvements, which require higher capital investment.

Recommendations have been proven by world-class smelters and are based upon world's current best practises – if adopted; smelters stand to achieve significant improvement in their environmental performance.

The ultimate aim of the guide is to provide practical and technical information to help all smelters in China achieve significant reductions in fluoride emissions, reducing the overall environmental impact of the smelting industry in China.

The guide has been prepared by the Light Metals Research Centre (LMRC), the University of Auckland, on the invitation of the Australian Aluminium Council (AAC), under the Asia-Pacific Partnership (APP) on Clean Development and Climate.

1.2 Scope of the Guide







What emissions & types of smelters are covered by the guide?



The FEMG covers fluoride emissions from primary aluminium smelters, concentrating on the potroom and gas treatment centre, as well as audits required and overall smelter systems that contribute to emissions.

The guide focuses on pre-bake, point-fed pot technologies and injection-type dry scrubbing technologies, which cover over 90% of all Chinese aluminium smelters. The full scope of the FEMG is illustrated in Table 1.1.

Table 1.1 - Scope of the FEMG.

Elements in the FEMG	What IS COVERED In the FEMG? 	What's NOT covered in the FEMG? 
Environmental Emission Type	Fluoride emissions only , including: - Gaseous fluorides, HF - Particulate fluorides 	Non-fluoride emissions , including: - SO₂, CO, CO₂ - Polycyclic Aromatic Hydrocarbons (PAH's) - Perfluorocarbons (PFC's), CF₄, C₂F₆
Potroom / Pot Design	Pre-bake pot design Point-fed 	Söderberg pot design Bar-break / side-work designs 
Gas Treatment Centre / Scrubber Design	Dry scrubbers, with an injection-type reactor and bag-house 	Wet scrubbers - Dry scrubbers, with alternate technology like Torroidal or fluidised bed

1.3 Structure of the Guide



What kind of information does the guide provide?



The FEMG covers 6 main sections for understanding and controlling fluoride emissions:

1. **Introduction & Theory** – Drivers behind reducing fluoride emissions, and background into how fluoride emissions are generated.
2. **Overall Fluoride Emission Management System** – Overall concept and approach for controlling and managing smelter fluoride emissions.
3. **Potroom Systems for Reducing Fluoride** – Key Process Indicators (KPI) and control points for operations/control & maintenance practises in the potroom.
4. **Gas Treatment Centre for Reducing Fluoride** – Key Process Indicators (KPI) and control points for operations/control & maintenance practises for the gas treatment centre.
5. **Smelter Systems Outside the Potroom and Gas Treatment Centre** – Key Process Indicators (KPI) and control points for other areas in the smelter that affect fluoride emissions.
6. **Fluoride Emission Measurements** – Standard and recommended smelter fluoride measurement methods.

Where possible in the guide, improvements to practises will be focused on over technology improvements, with recommendations ranked from requiring little/no capital investment to significant capital investment.




Figure 1.1 – Structure of the FEMG.

1.4 Drivers Behind Fluoride Emission Control



Why is controlling & reducing fluoride emissions important?



All aluminium smelters in the world, including those in China, are driven by the same factors for reducing the amount of fluorides they release into the environment. These factors are legal, health and environment, as well as operations or performance as illustrated by the chart below.

It is important to note that by implementing the best practices in this FEMG, each smelter has the potential to not only make significant improvements in environmental performance, but also significant improvements in the smelter's key operating performance measures, e.g. reductions in specific energy consumption, higher current efficiency, reductions in material losses, and so on.




Figure 1.2 – Chart showing why smelters need to make practical steps to reduce its fluoride emissions.



What are the legal limits for fluoride emissions?



Best Practises & Legal Requirements for Fluoride Emissions

All smelters worldwide, including those in China, operate under strict limits for fluoride emissions. Smelters which cannot meet these limits stand to lose their operating license and may be required to stop production or shut down.

These regulatory emission limits are typically benchmarked by what can be achieved by the best performing smelters of a particular technology, i.e. for pre-baked, point fed pot technologies. The table below shows a comparison of production-based regulatory limits for primary aluminium smelters for different regions in the world, including the current world's best practise.

Table 1.2 – Comparison of production based regulatory limits and the current world's best practise for total (stack + fugitive) airborne fluoride emissions.

Region		Regulated Airborne Emission Limits Total Fluorides (kg F / t Al)
World Benchmark ^{1,2}		0.2
Europe – Iceland ³		0.35
Europe – OSPAR ⁴		0.6
Middle East		0.6 ⁵ -1.25 ⁶
Australia ⁷		0.6-1.0
USA – EPA ⁸		0.6-1.5
China ⁹		<i>To Be Advised</i>

Meeting Regulations from the Chinese Government

Fluoride emissions from primary aluminium smelters are regulated in China by the Ministry of Environmental Protection, under Regulation *GB 25465-2010, Emission Standard of Pollutants for Aluminium Industry for 2010*. The relevant regulatory limits for atmospheric fluoride emissions are presented in the Table 1.3.

¹ Lindsay, S.J. (2004) *TMS Alumina Short Course*

² Lindsay, S.J. (2007) *Effective Techniques to Control Fluoride Emissions, TMS Light Metals*.

³ Moras A., et. al (2010) *Modern Potline Gas Treatment Technology for High Amperage Pots – The Alcoa Fjardaal Experience, TMS Light Metals*.

⁴ Emission targets for 2010. OSPAR Recommendation 98/2 on Emission and Discharge Limit Values for Existing Aluminium Electrolysis Plants. www.ospar.org

⁵ Royal Commission for Yubail and Yanbu, Kingdom of Saudi Arabia. Royal Commission Environmental Regulations 2004. Note that the figure of 0.6 kg F / t Al is for potroom (i.e. fugitive) emission sources only.

⁶ Emission limits for Bahrain. Figure of 1.25 kg F/t Al is for both potroom fugitive + stack emissions.

⁷ NSW Government, Australia. Protection of the Environment Operations (Clean Air) Regulation 2010.

⁸ US EPA (1997) *40 CFR Parts 9, 60, and 63. Final Rule*.

⁹ Chinese National Standards, GB 25465-2010. *Emission Standard of Pollutants for Aluminium Industry for 2010*.

***Work Practices
(Operating, Control &
Maintenance)
covered in the FEMG***




Figure 2.2: Smelter work practices impact on fluoride emission.

***Pathways for Fluoride
Emission
for each smelter work
practice***





How does anode setting impact on fluoride emission?





Pathway 1: Opening hoods

- Pot suction is reduced when the hoods are open during anode setting, due to the loss of static pressure in the pot.
- When pot suction is reduced, the pot capture efficiency decreases and fluoride emission increases. This relationship has been extensively documented (illustrated in Figure 3.6).
- When the hoods are open for anode setting, particulate and gaseous fluorides escape from the anode cover material which is exposed to the air (illustrated in Figure 3.7).



Pathway 2: Broken crust and opening cavity

- During crust breaking, particulate and gaseous fluorides escape from the holes in the anode crust which is exposed to the air (illustrated in Figure 3.8).
- Fluorides are evolved and emitted from the open cavity after the anode butts are removed and molten bath is exposed to the air (illustrated in Figure 3.9)



***Good / Best Practices
vs. Poor Practices***




How to reduce fluoride emission during metal tapping?



Fluoride emissions from metal tapping can be minimised through the following best practice.


BAD Practice ❌

1




Opening the tap end doors of a group of pots which are to be tapped.

2



Releasing the extracted fumes to the potroom environment.


3



Leaving the tap hole open after completion of tapping.


GOOD Practice ✅

1




Opening the tap end door of a single pot right before tapping.

2



Connecting a hose onto the crucible vent and directing the extracted fumes back to the pot.

3



Sprinkling some crushed bath or alumina into the tap hole to help form a crust which closes the tap hole.

***Potential Improvements
for each work practice***

***Checklists for Auditing
work practices***

**What are the potential improvements?**

Potential improvement to reduce fluoride emission during gas flows & pressure drops over GTC compartments		
No Cost	1	Continuous monitoring of overall GTC gas flowrate & pressure drop, and adopt a pro-active culture to investigate and correct any abnormal deviations in either parameters, before they become major issues.
	2	Regular audit of long term gas flows through each GTC compartment and correct damper positions for each compartment to balance long term pressure drops.
	3	Regular audits of the main GTC fans to check that it is still meeting draft specifications – see Section 4.9 on maintenance.
Low Cost	1	Install system that allows monitoring of pressure drops over individual GTC compartments.
	2	Increase overall gas flow by operating fans at higher draft (if not already at design limit).
	3	Install bag filters with higher cloth area (e.g. star shaped bags) to lower bagfilter pressure drop. This can increase air-to-cloth ratio available, allowing increases in scrubbing capacity and overall gas flowrate.
High Cost	1	Additional scrubbing capacity (more main fans, more GTC reactors and baghouse compartments).
	2	Additional booster draft capacity potroom (separate auxiliary pot ducts or damper valves in pot ducts) to reduce fugitive emissions during anode setting & other pot operations.

 Checklist to reduce fluoride emission during control of gas flows & pressure drops over GTC compartments

	Check items				
1	Is overall inlet gas flow to the GTC normal?	YES		NO	
2	Is overall pressure drop across the whole GTC normal?	YES		NO	
3	Is gas flowing to each individual GTC compartment? Has this been checked physically / visually?	YES		NO	
4	Do any of the GTC compartments have low gas flow?	YES		NO	
5	Are the individual GTC compartment pressure drops and gas flowrates within specification and balanced?	YES		NO	

Fluoride Monitoring & Measurements



6.6 Continuous Fluoride Emission Monitoring



What are continuous fluoride measurements and what value can they offer?



In addition to the regulatory or standard fluoride measurement techniques presented in previous sections, continuous/real-time fluoride measurements have also been employed in many modern smelters around the world, particularly to monitor GTC stack fluoride emissions and potroom fugitive fluoride emissions. Although standard or regulatory measurement techniques are much more robust and accurate, they have the disadvantage of being relatively time-consuming, labour-intensive and only provide single emission data points for each measurement site, typically over a 24 hour period.

In contrast, continuous measurements provide smelter management/operations staff the ability to study or monitor fluoride emissions in real-time, i.e. in direct response to operations and process events (e.g. in the GTC or potroom, such as shown in Figure 6.18). As such they can be used to monitor the quality of different operations and work practices, e.g. anode setting, hooding quality on pots, etc.

A number of different technologies and providers exist in the industry for both GTC stack and potroom roof vent measurement. For gaseous HF emission, these include (but are not limited to)¹⁹:

- Tunable Diode Laser (TDL) Spectroscopy – Boreal Laser, OPSIS, LasIR, NEO
- Fourier Transform Infrared (FTIR) Spectroscopy – MDA FTR, MIDAC, Gasmet
- HeNe laser direct absorption – SBL.




Figure 6.18: Example of continuous HF emissions from a potroom roof, measured using Boreal laser over 24 hours.

¹⁹ Whiteley, K. (1998) Continuous Long Path Gaseous HF Monitoring in a Potroom Roof Vent. *Proc. 6th Australian Aluminium Smelting Workshop*

***Audit Survey Worksheets
for Potroom & GTC***

FLUORIDE EMISSIONS MANAGEMENT GUIDE (FEMG) GAS TREATMENT CENTRE (GTC) AUDIT SURVEY

Version 06.11.2010

Smelter		Area		Date & Time	
----------------	--	-------------	--	------------------------	--

Surveyor Name(s)		Host Name(s) & Position	
-------------------------	--	------------------------------------	--

GTC GENERAL INFORMATION

GTC Type		<i>E.g. single stage injector, two stage, etc.</i>
Year Installed		
No. of GTC Units		<i>Each GTC unit: A baghouse filter, reactor, flow damper</i>
No. of Pots Serviced		

GAS FLOW & PRESSURE DROPS OVER GTC UNITS

	Check items				
1	Is overall inlet gas flow to the GTC normal?	YES		NO	
2	Is overall pressure drop across the whole GTC normal?	YES		NO	
3	Is gas flowing to each individual GTC compartment? Has this been checked physically / visually?	YES		NO	
4	Do any of the GTC compartments have low gas flow?	YES		NO	
5	Are the individual GTC compartment pressure drops and gas flowrates within specification and balanced?	YES		NO	

The following are questions to ask or tasks to do in order to complete the above checklist.

- 1) How is the gas flow to each GTC compartment unit monitored?

- 2) Ask the operator to indicate on the SCADA system the gas flow and pressure drop for the following GTC parts. What are the process specification limits for the gas flow and pressure drop parameters and verify whether they are within the specified limits.

- Individual GTC unit (distribution across the units)
- Individual baghouse (distribution across the baghouses)
- Overall GTC

- 3) Are there any systems (e.g. alarms, manual observation, logging, automatic response, manual response) in place to address imbalances of gas flow or pressure drops?
